




# Montgomery Ward GEN-39500 Internal Power Supply Replacement

Written By: Dustin Platt



## INTRODUCTION

This is a guide for replacing the internal power supply unit.

---



### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
  - [Soldering Station](#) (1)
-

## Step 1 — Back Cover



- Remove the nine 35 mm Phillips screws securing the back cover of the case.


## Step 2



- Carefully remove the back cover.
- ⓘ Soldered wires connect electronics on the back cover to the internal electronics. Be careful not to break any connections.




### Step 3




- Unplug the black and yellow wires connecting the power supply unit to the rest of the electronics:
- ⓘ This is not necessarily required. This step is to allow the back cover more movement as you work on the inside of the unit.

### Step 4 — Internal Power Supply




- Unscrew the six 10 mm Phillips screws holding the mounting plate in place.

## Step 5



- Unsolder the wires connecting the power supply unit to the battery container.

## Step 6



- Remove the power supply unit.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 07:53:14 PM.